




Spare Parts



Think Technology AS

N-1930 Aurskog, Norway

Telephone: + 47 63 85 45 00 Telefax: + 47 63 85 45 01

E-mail: info@think.no

www.think.no

About this manual

The purpose of this manual is to give people maintaining the **TH!NK city** information on available spare parts, and necessary information to identify and to order the right spare parts.

With the chassis number to identify actual car, this catalog will have the information needed to specify the parts needed to serve just this car.

The latest update of the catalog is always available in the dealer website.

Any printed issue of this catalog is for information only and can not be used as secure reference for spare parts.

Using this manual

Available spare parts are marked with position numbers in circles and corresponding fastener kits are marked with numbers in squares. Part number, part description and quantity used per. car as well as any remarks are listed in text page to the right.

To find the content of a fastener kit, check the listing in FA1.

All used fastener items are listed in FA2, specifying total amount used for each car.

New part numbers have remarks for which parts they substitute, and reference to specific modifications if needed.

Where different parts fit different chassis numbers, this is specified. Arrows are pointing from and to which chassis numbers the parts fit.

Sample:

51	570.8123.A	SD - DAMPING 400X125	2	Replaces 570.8009.C
52	529.1000.I	ASSY ELECTRICAL SUB FRAME	1	XYCFT26B97J001234 → →XYCFT26B97J005678
52	529.1000.J	ASSY ELECTRICAL SUB FRAME	1	XYCFT26B97J005679 → → XYCFT26B97J009101
52	529.1000.K	ASSY ELECTRICAL SUB FRAME	1	XYCFT26B97J009102 →

Illustrations can be viewed in active 3D by clicking inside the illustration. The illustration switches to a 3D view without position numbers, and the illustration can be rotated to any position by holding the left mouse button and moving the cursor. Easiest control is obtained by activating tool button #2 from left in tool bar on top of viewer.

To return to initial view, activate the "house image" in tool bar above viewer.


Click actual part in viewer or description in model tree to the left. By right-clicking and marking **Part options** and then **Isolate**, and further the option: **Zoom to Part**, the part can be rotated and studied without interference from surrounding parts.

Option: **Disable 3D**, returns to the standard catalog view with position numbers.

Common abbreviations used:	ASSY	=	ASSEMBLY
	BRKT	=	BRACKET
	CHMSL	=	CENTRAL HIGH MOUNTED STOP LIGHT
	EL	=	ELECTRICAL
	LBL	=	LABEL
	LF	=	LOWER FRAME
	LH	=	LEFT HAND
	LWR	=	LOWER
	PCU	=	POWER CONTROL UNIT
	RH	=	RIGHT HAND
	UF	=	UPPER FRAME
	VS	=	VERSUS (Against)

Contents (click the actual line to activate group)


A01	FRAME
A02	BODY PANELS
A03	DOORS
A04	GLASS
A05	EXTERIOR TRIM
B01	MOTOR
B02	TRACTION BATTERY
B03	HIGH VOLTAGE HARNESS
C01	TRANSAXLE
C02	GEARSHIFT
C03	DRIVESHAFTS
D01	FRONT SUSPENSION
D02	REAR SUSPENSION
D03	STEERING
E01	BRAKES
E02	WHEELS
F01	VENTILATION SYSTEM
F02	HEATING SYSTEM
F03	AIR CONDITIONING
G01	BATTERY AND HARNESS
G02	RELAYS AND FUSES
G03	AUXILLIARIES
G04	LIGHTNING
G05	SWITCHES
G06	KEYS AND LOCKS
G07	INFOTAINMENT
H01	DASHBOARD
H02	SEATS
H03	SAFETY RESTRAINTS SYSTEM
H04	INTERIOR TRIM
Z01	ACCESSORIES
FA1	FASTENER KITS
FA2	FASTENER ITEMS



See page A01-05
for spare parts
breakdown

Click inside frame to activate 3D-view



Pos	Part no.	Description	Qty/Assy	Remarks
1	525.0001.L	LOWER FRAME GENERAL ASSEMBLY	1	SEE PAGE A01-05
2	525.8000.B	BATTERY ACCESS LID	1	
3	520.2900.A	FASTENERS, BATT ACC LID TO LF	1	
4	525.8300.D	SEAT DECK LID	1	
5	520.1200.C	FASTENERS, SEAT DECK LID TO LF	1	
6	522.0100.B	SEAT DECK GASKET	1	
7	520.0300.B	FASTENERS, UF TO LF W.HOUSE/VALANCE	1	
8	525.3700.D	FRONT SKID PLATE	1	
9	543.2090.B	BRACKET, SKID PLATE FRONT	1	
10	543.2095.A	FASTENER BRKT SKID PLATE FRONT	1	
11	543.2300.A	BRACKET, SKID PLATE REAR	1	
12	543.2310.A	FASTENER, BRKT SKID PLATE REAR	1	
13	520.1300.C	FASTENERS SKID PLATE TO LOWER FRAME	1	
14	523.0021.B	PAINTED SIDE UPPER FRAME LH	1	
15	568.0061.B	END CAP - CANTRAIL, LH	1	
16	568.8020.A	FASTENERS CANTRAIL CAP	1	
17	523.0022.B	PAINTED SIDE UPPER FRAME RH	1	
18	568.0062.B	END CAP - CANTRAIL, RH	1	
19	568.8020.A	FASTENERS CANTRAIL CAP	1	
20	523.0210A	PAINTED SCREEN HEADER ASSY	1	
21	523.0510.A	PAINTED REAR HEADER ASSY	1	
22	560.3131.A	SEAL CANT RAIL VS. REAR HEADER, LH	1	
23	560.3132.A	SEAL CANT RAIL VS. REAR HEADER, RH	1	
24	520.0090.A	FASTENERS SCR/REAR HEADER TO UF	1	
25	520.0100.C	FASTENERS UF TO LF A-POST & B-POST	1	
26	523.1000.B	BRACKET A-POST WASHER PLATE	2	
27	523.1101.B	BRACKET B-POST WASHER PLATE LH	1	
28	523.1102.B	BRACKET B-POST WASHER PLATE RH	1	
29	520.0200.C	FASTENERS, UF TO LF STRUT CONNECTION	1	
30	520.0400.B	FASTENERS, UF TO LLF SILL CONNECTION	1	
31	520.0500.B	FASTENERS, C-POST TO UPPER FRAME	1	
32	520.0600.B	FASTENERS, C-POST TO LOWER FRAME	1	
33	565.0020.F	UPPER BULKHEAD PANEL, FRONT	1	
34	565.0031.D	UPPER BULKHEAD PANEL, LH	1	
35	565.0032.D	UPPER BULKHEAD PANEL, RH	1	
36	565.8000.B	FASTENERS UPPER BULKHEAD PANEL	1	



See page A01-05
for spare parts
breakdown

Click inside frame to activate 3D-view



Pos	Part no.	Description	Qty/Assy	Remarks
37	527.0001.G	ASSY DASHBOARD STRUCTURE	1	
38	525.7900.C	DASHBOARD BULKHEAD MOUNT	1	
39	520.3100.A	FASTENERS, DASH BULKHEAD MNT TO LF	1	
40	527.0003.G	ASSY KNEE BOLSTER STRUCTURE	1	
41	520.0900.B	FASTENERS KNEE BOLSTER TO UF	1	
42	520.0700.B	FASTENERS DASH CROSS BEAM TO UF	1	
43	520.0800.B	FASTENERS DASH CROSS BEAM TO LF	1	
44	553.2080.A	PLUG - A/C BULKHEAD	1	
45	560.0280.D	BRACKET, IEC 309	1	
46	560.8110.B	FASTENERS BRACKET IEC 309	1	
47	565.3001.C	SEAL BULKHEAD SIDES VS. A-POST LH	1	
48	565.3002.C	SEAL BULKHEAD SIDES VS. A-POST RH	1	
49	565.3011.C	SEAL BULKHEAD SIDES VS. CANTRAIL LH	1	
50	565.3012.C	SEAL BULKHEAD SIDES VS. CANTRAIL RH	1	
51	565.3020.D	SEAL BULKHEAD VS.TOP CROSSMEMBER	1	
52	565.3040.C	SEAL BULKHEAD VS.POLLEN FILTER	2	
53	570.8009.C	SD - DAMPING 400X125	2	
54	529.1000.I	ASSY ELECTRICAL SUB FRAME	1	
55	520.2100.B	FASTENERS EL.SUBFRAME TO FRAME RAILS	1	
56	520.2200.C	FASTENERS EL.SUBFRAME TO STRUT TOWERS	1	



Parts not available as spare parts

Click inside frame to activate 3D-view



Pos	Part no.	Description	Qty/Assy	Remarks
57	524.1200.B	VENT PIPE	1	
58	525.0100.J	FRONT BUMPER ARMATURE	1	
59	525.0200.E	FRONT BUMPER CLOSURE	1	
60	525.0601.E	TOWER LH	1	
61	525.0602.E	TOWER RH	1	
62	525.0701.H	SILL OUTER LH	1	
63	525.0702.H	SILL OUTER RH	1	
64	525.0801.J	SILL INNER LH	1	
65	525.0802.J	SILL INNER RH	1	
66	525.1500.D	UNIVERSAL BRACKET	1	
67	525.1901.B	C-PILLAR MOUNTING BRKT LH	1	
68	525.1902.B	C-PILLAR MOUNTING BRKT RH	1	
69	525.2200.F	REAR BUMPER ARMATURE	1	
70	525.2300.D	REAR BUMPER CLOSURE	1	
71	525.2401.E	A-POST REINFORCEMENT LH	1	
72	525.2402.E	A-POST REINFORCEMENT RH	1	
73	525.2501.E	B-POST REINFORCEMENT LH	1	
74	525.2502.E	B-POST REINFORCEMENT RH	1	
75	525.2801.F	FRONT SUSPENSION BRKT OUTER LH	1	
76	525.2802.F	FRONT SUSPENSION BRKT OUTER LH	1	
77	525.2901.D	FRONT SUSPENSION BRKT INNER LH	1	
78	525.2902.D	FRONT SUSPENSION BRKT INNER LH	1	
79	525.3301.B	BUMP STOP BRKT LH	1	
80	525.3302.B	BUMP STOP BRKT RH	1	
81	525.3401.E	STRUT TOP LH	1	
82	525.3402.E	STRUT TOP RH	1	
83	525.3601.F	BULLSHORN LH	1	
84	525.3602.F	BULLSHORN RH	1	
85	525.4001.C	RR SUSPENSION MTG BRKT FRONT LH	1	
86	525.4002.C	RR SUSPENSION MTG BRKT FRONT RH	1	
87	525.4100.C	REAR SUSPENSION MOUNTING BRKT REAR	2	
88	525.4501.C	EXTENSION FRONT BUMPER LH	1	
89	525.4502.C	EXTENSION FRONT BUMPER RH	1	
90	525.4601.F	FRONT RAIL INNER LH	1	
91	525.4602.F	FRONT RAIL INNER RH	1	



Parts not available as
spare parts



Click inside frame to activate 3D-view

Pos	Part no.	Description	Qty/Assy	Remarks
92	525.4701.F	FRONT RAIL OUTER LH	1	
93	525.4702.F	FRONT RAIL OUTER RH	1	
94	525.5100.F	REAR DIVIDER WALL	1	
95	525.5201.C	REAR SUSPENSION CORNER REINF. LH	1	
96	525.5202.C	REAR SUSPENSION CORNER REINF. RH	1	
97	525.5300.C	REAR BUMPSTOP MOUNTING STRIP	2	
98	525.6400.A	REAR SUSPENSION SPACER	2	
99	525.6500.A	REAR SUSP MTG BRKT UPPER	2	
100	525.7700.F	FRONT TOW EYE	1	
101	525.7750.A	FRONT TOW EYE ROD	1	
102	525.8700.E	REAR MOTOR MOUNT FRAME	1	
103	525.9200.D	FRONT MOTOR MOUNT FRAME	1	
104	525.9600.D	REAR TIE DOWN	1	
105	525.9701.H	EL. SUBFRAME MOUNTING BRKT LH	1	
106	525.9702.H	EL. SUBFRAME MOUNTING BRKT RH	1	
107	525.9800.C	REINFORCEMENT SEATBELT RETRACTOR	2	





Click inside frame to activate 3D-view

Pos	Part no.	Description	Qty/Assy	Remarks
1	562.0910.C	LBL - DIPPED BEAM INCLINATION	1	
2	565.0011.D	LEAF SCREEN, LH	1	
3	565.0012.D	LEAF SCREEN, RH	1	
4	565.8040.C	FASTENERS LEAF SCREEN	1	
5	565.0130.A	WIPER SHAFT AND POST SEAL	1	
6	560.1021.E	FRONT FENDER ASSY LH		
	- 08	FRONT FENDER ASSY LH BLACK	1	
	- 09	FRONT FENDER ASSY LH RED	1	
	- 10	FRONT FENDER ASSY LH BLUE	1	
	- 11	FRONT FENDER ASSY LH YELLOW	1	
7	560.0241.D	BRACKET FENDER,RR, LH	1	
8	560.0291.D	BRACKET FENDER FRONT LH	1	
9	560.8190.B	FASTENERS BRACKET FRONT FENDER	2	
10	560.8130.B	FASTENERS BRACKET FENDER	2	
11	560.8060.C	FASTENERS FENDER	2	
12	568.0021.D	FINISHER FRONT QUARTER, LH	1	
13	568.0081.A	BRKT FRONT QUARTER FINNISHER, LH	1	
14	568.0082.A	BRKT FRONT QUARTER FINNISHER, RH	1	
15	568.8050.B	FASTENERS FINISHER FRONT QUARTER	2	
16	567.0081.E	FRONT WHEELHOUSE LINER LH	1	
17	567.8030.C	FASTENERS FRONT WHEELHOUSE	2	
18	560.1022.E	FRONT FENDER ASSY RH		
	- 08	FRONT FENDER ASSY RH BLACK	1	
	- 09	FRONT FENDER ASSY RH RED	1	
	- 10	FRONT FENDER ASSY RH BLUE	1	
	- 11	FRONT FENDER ASSY RH YELLOW	1	
19	560.0242.D	BRACKET FENDER,RR,RH	1	
20	560.0292.D	BRACKET FENDER FRONT RH	1	
21	568.0022.D	FINISHER FRONT QUARTER, RH	1	
22	567.0082.E	FRONT WHEELHOUSE LINER RH	1	
23	568.0010.F	FRONT GRILLE	1	
24	568.8040.B	FASTENERS FRONT GRILLE	1	
25	568.0011.A	GRILLE LOGO SILVER	1	
26	568.0015.B	FRONT GRILLE SILVER	1	
27	568.0016.A	GRILLE LOGO BLACK	1	




Click inside frame to activate 3D-view

Pos	Part no.	Description	Qty/Assy	Remarks
28	560.0070.E	CHARGE INLET DOOR		
	- 08	CHARGE INLET DOOR BLACK	1	
	- 09	CHARGE INLET DOOR RED	1	
	- 10	CHARGE INLET DOOR BLUE	1	
	- 11	CHARGE INLET DOOR YELLOW	1	
29	560.0170.E	REINFORCEMENT, CHARGE DOOR		
30	560.0175.B	SPRING, CHARGE DOOR	1	
31	560.0177.A	MAGNET, CHARGE DOOR	1	
32	560.0300.D	STRIKER, CHARGE DOOR	1	
33	560.0305.A	MAGNET STRIKER, CHARGE DOOR	1	
34	560.0400.A	LBL - CHARGE DOOR, ZEBRA	1	
35	560.0420.A	LBL - CHARGE DOOR, HV WARNING	1	
36	560.3010.C	SEAL CHARGE DOOR	1	
37	567.1010.E	FRONT BUMPER ASSEMBLY		
	- 08	FRONT BUMPER ASSEMBLY BLACK	1	
	- 09	FRONT BUMPER ASSEMBLY RED	1	
	- 10	FRONT BUMPER ASSEMBLY BLUE	1	
	- 11	FRONT BUMPER ASSEMBLY YELLOW	1	
38	560.0230.C	BRACKET FRONT BUMPER	1	
39	567.0120.A	BRKT FRONT BUMPER LOWER, LH	1	
40	567.0130.A	BRKT FRONT BUMPER LOWER, RH	1	
41	560.8180.C	FASTENERS BRACKET FRONT BUMPER	1	
42	567.8010.C	FASTENERS FRONT BUMPER	1	
43	567.0010.E	FRONT BUMPER FOAM	1	
44	560.1010.E	HOOD PANEL ASSY		
	- 08	HOOD PANEL ASSY BLACK	1	
	- 09	HOOD PANEL ASSY RED	1	
	- 10	HOOD PANEL ASSY BLUE	1	
	- 11	HOOD PANEL ASSY YELLOW	1	
45	560.0360.A	BUMP STOP - HOOD	2	
46	560.0201.E	BRACKET HOOD HINGE,LH	1	
47	560.0202.E	BRACKET HOOD HINGE,RH	1	
48	560.8150.C	FASTENERS BRACKET HOOD HINGE	1	
49	560.0210.D	BRACKET UPPER HOOD HINGE	2	
50	560.8140.B	FASTENERS HOOD HINGE	1	
51	563.0100.E	PROP-HOOD	1	




Click inside frame to activate 3D-view

Pos	Part no.	Description	Qty/Assy	Remarks
52	560.8170.D	FASTENERS HOOD	1	
53	563.0010.B	PIN - HOOD STRIKER	1	
54	563.0110.B	NUT - HOOD STRIKER	1	
55	563.0120.B	SPRING - HOOD STRIKER	1	
56	563.0130.B	CUP - HOOD STRIKER	1	
57	563.0200.B	BRACKET HOOD STRIKER	1	
58	543.2071.A	HOOD AJAR SWITCH	1	
59	563.0140.A	GUIDE PLATE - HOOD LATCH	1	
60	563.0020.A	LATCH - HOOD	1	
61	563.8050.B	FASTENERS HOOD LATCH	1	
62	563.0040.A	HANDLE - HOOD RELEASE	1	
63	563.8070.B	FASTENERS HANDLE RELEASE HOOD	1	
64	563.0210.C	BRACKET HOOD RELEASE HANDLE	1	
65	563.8060.B	FASTENERS BRACKET HOOD RELEASE	1	
66	563.0030.C	CABLE - HOOD RELEASE	1	




Click inside frame to activate 3D-view

Pos	Part no.	Description	Qty/Assy	Remarks
67	560.1061.A	ROCKER PANELS ASSY LH		
	- 08	ROCKER PANELS ASSY LH BLACK	1	
	- 09	ROCKER PANELS ASSY LH RED	1	
	- 10	ROCKER PANELS ASSY LH BLUE	1	
	- 11	ROCKER PANELS ASSY LH YELLOW	1	
68	570.8041.F	INT. SILL PROTECTION, LH	1	
69	570.8050.C	FASTENERS - SILL PROTECTION	2	
70	560.8020.C	FASTENERS ROCKER PANEL	2	
71	560.1062.A	ROCKER PANELS ASSY RH		
	- 08	ROCKER PANELS ASSY RH BLACK	1	
	- 09	ROCKER PANELS ASSY RH RED	1	
	- 10	ROCKER PANELS ASSY RH BLUE	1	
	- 11	ROCKER PANELS ASSY RH YELLOW	1	
72	570.8042.F	INT. SILL PROTECTION, RH	1	
73	504.0010.D	SEAL - PRIMARY, DOOR	2	
74	560.1070.A	REAR END PANEL ASSY	1	
75	560.8070.C	FASTENERS REAR END PANEL	1	
76	560.8080.B	FASTENERS REAR END TO BODYSIDE	1	
77	570.1055.E	LIFT GATE SILLMOULDING	1	
78	570.1056.C	FASTENERS - LIFTGATE SILLMOULDING	1	
79	560.1041.G	BODYSIDE ASSY LH		
	- 08	BODYSIDE ASSY LH BLACK	1	
	- 09	BODYSIDE ASSY LH RED	1	
	- 10	BODYSIDE ASSY LH BLUE	1	
	- 11	BODYSIDE ASSY LH YELLOW	1	
80	560.3141.A	SEAL BODYSIDE INNER VS. LAMP PANEL, LH	1	
81	560.8040.C	FASTENERS BODYSIDE	2	
82	570.8009.C	SD - DAMPING 400X125	2	
83	567.0091.G	REAR WHEELHOUSE LINER LH	1	
84	570.8007.C	SD - DAMPING 800X125	2	
85	567.8040.C	FASTENERS REAR WHEELHOUSE	2	
86	560.1042.G	BODYSIDE ASSY RH		
	- 08	BODYSIDE ASSYRH BLACK	1	
	- 09	BODYSIDE ASSY RH RED	1	
	- 10	BODYSIDE ASSY RH BLUE	1	
	- 11	BODYSIDE ASSY RH YELLOW	1	




Click inside frame to activate 3D-view

Pos	Part no.	Description	Qty/Assy	Remarks
87	560.3142.A	SEAL BODYSIDE INNER VS. LAMP PANEL, RH	1	
88	567.0092.G	REAR WHEELHOUSE LINER RH	1	
89	567.1020.E	REAR BUMPER ASSEMBLY		
	- 08	REAR BUMPER ASSEMBLY BLACK	1	
	- 09	REAR BUMPER ASSEMBLY RED	1	
	- 10	REAR BUMPER ASSEMBLY BLUE	1	
	- 11	REAR BUMPER ASSEMBLY YELLOW	1	
90	567.0111.A	BRKT REAR BUMPER LOWER, LH	1	
91	567.0112.A	BRKT REAR BUMPER LOWER, LH	1	
92	567.8020.C	FASTENERS REAR BUMPER	1	
93	567.0020.E	REAR BUMPER FOAM	1	
94	560.0080.F	ROOF PANEL	1	




Click inside frame to activate 3D-view

Pos	Part no.	Description	Qty/Assy	Remarks
1	526.0001.J	DOOR ASSEMBLY LH	1	
2	570.8005.C	SD - DAMPING 280X200	4	
3	560.0031.G	DOOR PANEL OUTER, LH		
	- 08	DOOR PANEL OUTER, LH BLACK	1	
	- 09	DOOR PANEL OUTER, LH RED	1	
	- 10	DOOR PANEL OUTER, LH BLUE	1	
	- 11	DOOR PANEL OUTER, LH YELLOW	1	
4	560.8050.C	FASTENERS DOOR	2	
5	503.4011.A	DOOR HINGE LH	2	
6	503.0120.C	FASTENERS DOOR HINGES-DOOR	2	
7	503.0130.C	FASTENERS DOOR HINGES-FRAME	2	
8	503.4040.B	BRKT NUT PLATE DOOR HINGE M10 2 HOLES	4	
9	503.4010.D	CHECK ASSY DOOR	2	
10	503.0140.C	FASTENERS DOOR CHECK ARM	2	
11	504.0020.A	SEAL - WAIST, INNER - DOOR	2	
12	504.0030.D	SEAL - WAIST, OUTER - DOOR	2	
13	504.0051.E	SEAL GLASS RUN, DOOR LH	1	
14	526.0051.G	GLASS HOLDER FRAME ASSEMBLY LH	1	
15	526.0061.F	WAIST RAIL OUTER LH	1	
16	568.0031.F	FRONT CAP-WAISTRAIL, LH	1	
17	568.8030.C	FASTENERS FRONT WAISTRAIL CAP	2	
18	568.0041.C	WAISTRAIL CAP, REAR LH	1	
19	568.8010.C	FASTENERS WAISTRAIL CAP	2	
20	503.5001.A	CENTRAL LOCK SYSTEM ASSY , LH	1	
21	503.5003.B	MAN LATCH SYSTEM ASSY, LH	1	
22	503.5050.A	MAN WIRE INSIDE HANDLE	2	
23	503.5040.A	DOOR LATCH STRIKER	2	
24	503.0070.D	FASTENERS DOOR LATCH	2	
25	503.0080.C	FASTENERS DOOR LATCH STRIKER	2	
26	503.5060.A	PLATE STRIKER PIN	2	
27	503.7020.B	BRKT STRIKER HOLDER	2	
28	503.0160.C	FASTENERS DOOR STRIKER BRKT	2	
29	503.5010.B	OUTSIDE HANDLE	2	
30	503.0040.C	FASTENERS DOOR OUTER HANDLE PLATE	2	
31	503.5061.E	BRKT OUTSIDE HANDLE, DOOR, LH	1	
32	503.0110.C	FASTENERS DOOR OUTER HANDLE BRKT	2	




Click inside frame to activate 3D-view

Pos	Part no.	Description	Qty/Assy	Remarks
33	503.5080.A	ROD OUTER HANDLE	2	
34	503.5120.B	BEZEL OUTSIDE HANDLE WITH LOCK CYL.	2	
35	503.5170.A	ADJUSTABLE CLIP ROD OUTER HANDLE	2	
36	503.5160.A	PAD OUTER HANDLE	2	
37	503.5210.A	CLIP ROD OUTER HANDLE	2	
38	503.5051.A	HANDLE PLATE LH WITH LOCK CYL.	1	
39	570.4100.F	ASSY - DOOR PANEL TRIM, LH	1	
40	570.4150.C	FASTENERS - DOOR PANEL TRIM LH/RH	2	
41	572.1061.A	SPEAKER GRILL LH/RH	2	
42	503.7001.B	WATER SHEDDER LH	1	
43	570.4009.A	INT. DOOR INSERT ARMREST, LH/RH	2	
44	570.4011.H	COIN TRAY FOR PULL CUP APERTURE LH/RH	2	
45	503.5021.A	DOOR INSIDE HANDLE LH	1	
46	503.5011.A	BEZEL DOOR INSIDE HANDLE LH	1	
47	503.0050.C	FASTENERS DOOR INSIDE HANDLE BEZEL	2	
48	526.0101.E	BRKT INSIDE HANDLE LH	1	
49	503.0060.C	FASTENERS DOOR INSIDE HANDLE BRKT	2	
50	503.5100.A	COVER INSIDE HANDLE SCREW	2	
51	503.5110.A	RETAINER CLIP	2	
52	502.2121.B	REG ASSY POWER DOOR WINDOW LH	1	
53	503.0100.C	FASTENERS DOOR GLASS REGULATOR MECH	2	
54	503.5071.A	ROD LOCK BARREL LH	1	
55	526.0002.J	DOOR ASSEMBLY RH	1	
56	560.0032.G	DOOR PANEL OUTER, RH		
	- 08	DOOR PANEL OUTER, RH BLACK	1	
	- 09	DOOR PANEL OUTER, RH RED	1	
	- 10	DOOR PANEL OUTER, RH BLUE	1	
	- 11	DOOR PANEL OUTER, RH YELLOW	1	
57	503.4012.A	DOOR HINGE RH	2	
58	504.0052.E	SEAL GLASS RUN, DOOR RH	1	
59	526.0052.G	GLASS HOLDER FRAME ASSEMBLY RH	1	
60	526.0062.F	WAIST RAIL OUTER RH	1	
61	568.0032.F	FRONT CAP-WAISTRAIL, RH	1	
62	568.0042.C	WAISTRAIL CAP, REAR RH	1	
63	503.5002.A	CENTRAL LOCK SYSTEM ASSY , RH	1	
64	503.5004.B	MAN LATCH SYSTEM ASSY, RH	1	




Click inside frame to activate 3D-view

Pos	Part no.	Description	Qty/Assy	Remarks
65	503.5062.E	BRKT OUTSIDE HANDLE, DOOR, RH	1	
66	503.5130.B	BEZEL OUTSIDE HANDLE W/O LOCK CYL.	1	
67	503.5092.A	HANDLE PLATE RH W/O LOCK CYL.	1	
68	570.4200.F	ASSY - DOOR PANEL TRIM, RH	1	
69	570.4095.B	FASTENERS - DOOR POCKET FRAME LH/RH	1	
70	503.7002.B	WATER SHEDDER RH	1	
71	503.5022.A	DOOR INSIDE HANDLE RH	1	
72	503.5012.A	BEZEL DOOR INSIDE HANDLE RH	1	
73	526.0102.E	BRKT INSIDE HANDLE RH	1	
74	502.2122.B	REG ASSY POWER DOOR WINDOW RH	1	
75	503.5072.A	ROD LOCK BARREL RH	1	



Click inside frame to activate 3D-view


Pos	Part no.	Description	Qty/Assy	Remarks
76	566.1100.B	ASSY LIFTGATE	1	
77	566.8050.G	FASTENERS GAS STRUT BRKT LWR	1	
78	566.8060.G	FASTENERS STRIKER MOULDING	1	
79	563.0050.A	LIFTGATE STRIKER	1	
80	566.8070.B	FASTENERS LIFGATE STRIKER	1	
81	566.8080.C	FASTENERS LIFGATE	1	
82	566.1000.C	ASSY UPPER SPOILER	1	
83	566.8030.C	FASTENERS UPR SPOILER	1	
84	566.0030.B	GAS STRUT	2	
85	566.8090.B	FASTENERS GAS STRUT	1	
86	566.3000.B	SEAL GAS STRUT FIXING	2	
87	566.0040.C	LIFTGATE HINGE	2	
88	566.8020.C	FASTENERS LIFTGATE HINGE	1	
89	566.0221.C	LIFTGATE HINGE MNTG, LH	1	
90	566.0222.C	LIFTGATE HINGE MNTG, RH	1	
91	566.8010.B	FASTENERS LIFTGATE HINGE BRKT	1	
92	563.0240.F	BRKT LIFTGATE LATCH	1	
93	563.8030.C	FASTENERS LIFTGATE LATCH BRKT	1	
94	563.0060.A	LIFTGATE LATCH	1	
95	563.8010.B	FASTENERS LIFTGATE LATCH	1	
96	563.0070.A	LIFTGATE LATCH ROD	1	
97	563.0080.A	LIFTGATE LATCH ACTUATOR	1	
98	563.8040.B	FASTENERS LIFTGATE LATCH ACTUATOR	1	
99	563.0090.A	SWITCH LIFTGATE SENSOR	1	
100	563.0230.A	MOUNTING STAPLE SWITCH	1	
101	566.0090.D	LIFTGATE SEAL	1	



Click inside frame to activate 3D-view


Pos	Part no.	Description	Qty/Assy	Remarks
1	561.0010.D	WINDSCREEN	1	
2	561.0015.B	WINDSCREEN HEATED	1	
3	570.1021.B	INTERIOR MIRROR	1	
4	570.1022.A	INTERIOR MIRROR BRACKET	1	
5	502.0001.E	DOOR GLASS ASSY, LH	1	
6	503.0170.C	FASTENERS DOOR GLASS	2	
7	502.0002.E	DOOR GLASS ASSY, RH	1	
8	561.0031.C	QUARTERGLASS, LH	1	
9	568.0051.E	QUARTERLIGHT FINISHER LH	1	
10	561.0032.C	QUARTERGLASS, RH	1	
11	568.0052.E	QUARTERLIGHT FINISHER RH	1	
12	564.1011.F	OUTSIDE MIRROR ASSY, LH (EU)	1	
13	564.1012.F	OUTSIDE MIRROR ASSY, RH (EU)	1	

A05 Exterior Trim




To be added later

A05 Exterior Trim



To be added later




CAUTION
KEEP HANDS CLEAR
FAN MAY ENGAGE WHEN ENGINE IS OFF



Click inside frame to activate 3D-view

Pos	Part no.	Description	Qty/Assy	Remarks
1	590.1030.D	MOTOR	1	
2	528.0200.E	BRKT ASSY REAR MOTOR MOUNT	1	
3	528.6060.B	RUBBER MOTOR MOUNT	1	
4	520.1900.C	FASTENERS RR MOTOR MOUNT TO TRANNY	1	
5	520.2000.C	FASTENERS RR MOTOR MOUNT TO LF	1	
6	520.2800.B	FASTENERS REAR M. MNT ADPTR TO MOTOR	1	
7	528.0300.E	BRKT ASSY FRONT MOTOR MNT	1	
8	528.6060.B	RUBBER MOTOR MOUNT	1	
9	520.1500.B	FASTENERS FRT MOTOR MOUNT TO TRANNY	1	
10	520.1600.C	FASTENERS FRT MOTOR MOUNT TO LF	1	
11	528.0430.C	BRKT OFFSET MOTOR MOUNT HANGER	1	
12	520.1700.B	FASTENERS SIDE MOTOR MOUNT TO MOTOR	1	
13	528.0400.E	BRKT SIDE MOTOR MOUNT FRAME ASSY	1	
14	528.6060.B	RUBBER MOTOR MOUNT	1	
15	520.1800.B	FASTENERS SIDE MOTOR MOUNT TO LF	1	
16	528.0420.B	BRKT SIDE MOTOR MOUNT ADAPTER	1	
17	590.2000.E	POWER CONTROL UNIT	1	
18	590.2010.B	FASTENERS PCU	1	
19	590.2011.A	PCU BOLT PACKET A	1	
20	590.2012.A	PCU BOLT PACKET B	1	
21	590.2013.A	PCU BOLT PACKET C	1	
22	590.2014.A	PCU BOLT PACKET D	1	
23	590.2015.A	PCU BOLT PACKET E	1	
24	522.0300.A	PCU COVER PLATE	1	
25	542.1110.B	PLUG, DUMMY A/C	1	
26	543.1050.A	SENSORASSY ENGINE TEMP SENSOR	1	
27	529.6100.C	PCU MOUNTING BRACKET	1	
28	529.6401.B	PCU MOUNTING BRACKET UPPER LHS	1	
29	529.6402.C	PCU MOUNTING BRACKET UPPER RHS	1	
30	520.2500.B	FASTENERS PCU MNTG BRKT TO PCU	1	
31	529.6500.E	PCU ISOLATOR RUBBER	4	
32	520.2600.C	FASTENERS PCU ISOLATORS	1	
33	550.1020.D	RADIATOR & FAN ASSY	1	
34	550.9020.A	LBL - FAN WARNING	1	
35	550.1060.A	RESISTOR	1	
36	550.1070.A	RADIATOR CORE	1	




CAUTION
KEEP HANDS CLEAR
FAN MAY ENGAGE WHEN ENGINE IS OFF




Click inside frame to activate 3D-view

Pos	Part no.	Description	Qty/Assy	Remarks
37	550.1080.A	RADIATOR FAN SHROUD	1	
38	550.1090.A	COOLING FAN	2	
39	550.8020.B	FASTENER - RAD & FAN ASSY	1	
40	550.1010.D	COOLING PUMP	2	
41	550.8080.A	FASTENER - COOLING PUMP	1	
42	550.1160.B	BRKT-COOLING PUMP	1	
43	550.8030.B	FASTENER - BRKT COOLING PUMP	1	
44	550.8090.A	FASTENER - COOLING PUMP 2	1	
45	550.1170.B	BRKT-COOLING PUMP 2	1	
46	550.8070.A	FASTENER - BRKT COOLING PUMP 2	1	
47	550.1040.B	COOLANT RESERVOIR	1	
48	550.1150.A	COOLANT RESERVOIR CAP	1	
49	550.9030.A	LBL - RAD FILL CAP	1	
50	550.8010.E	FASTENER - COOLANT RESERVOIR	1	
51	550.1140.G	BRKT COOLANT RESERVOIR REAR	1	
52	550.8040.C	FASTENER - BRKT COOLANT RESERVOIR REAR	1	
53	550.2010.E	HOSE RADIATOR TO PCU	1	
54	550.8060.A	FASTENER - HOSE RADIATOR TO PCU	1	
55	550.2030.G	HOSE PCU TO MOTOR	1	
56	550.8050.B	FASTENER - HOSE PCU TO MOTOR	1	
57	550.2040.D	HOSE MOTOR TO RADIATOR	1	
58	535.1010.C	ACCELERATOR PEDAL	1	
59	535.1020.D	FASTENERS-ACCELERATOR PEDAL	1	




Click inside frame to activate 3D-view

Pos	Part no.	Description	Qty/Assy	Remarks
1	515.1710.B	TRAC BATT Z57-253-ML3P-76	1	
2	541.2030.B	CABLE TRACTION BATTERY TO GND	1	
3	543.2025.A	FASTENER CBL TRACTION BATT TO GND	1	
4	524.3010.A	BATTERY RETENTION WASHER	6	
5	524.3020.C	BATTERY RETENTION STRAP LONG	3	
6	520.2300.C	FASTENERS TRACKTION BATTERY RETENTION	1	
7	570.3014.A	SWITCH - TRACTION BATTERY RESET	1	
8	514.0100.B	TRACTION BATTERY COOLING FAN	1	
9	514.0400.C	BRKT, TRACTION BATTERY COOLING FAN	1	
10	514.0433.A	SILENCER BRASS PART	3	
11	514.0434.A	SILENCER RUBBER PART	3	
12	514.0410.C	FASTENER ASSY, COOLING FAN TO BRKT	1	
13	514.0420.E	FASTENER ASSY, FAN BRKT TO LOWER FRAME	1	
14	514.0210.C	ASSY HOSE, TRAC BATT INTAKE TO FAN	1	
15	514.0220.B	ASSY HOSE, TRAC BATT INTAKE TO BATT	1	
16	514.0230.B	ASSY HOSE, TRAC BATT EXHAUST TO BATT	1	
17	514.0240.B	ASSY HOSE, TRAC BATT EXHAUST TO FRAME	1	
18	551.3010.A	AIR EXTRACTOR	1	
19	514.0500.E	SAFETY THERMAL SHEET TRACTION BATTERY	1	
20	514.0511.B	SAFETY THERMAL SHEET GLASS FABRIC	1	
21	514.0515.C	ASSY- BATTERY CASING INSULATION	1	
22	514.0440.A	PROTECTION ANGLE FOR BATTERY STRAPS	1	
23	514.0510.C	TOP THERMAL SHEET TRACTION BATTERY	1	
24	514.0520.C	BELOW SEAT DECK INSULATION FRONT	1	
25	514.0530.C	BELOW SEAT DECK INSULATION MIDDLE	1	
26	514.0540.C	BELOW SEAT DECK INSULATION REAR	1	
27	514.0550.C	BELOW INSPECTION HATCH INSULATION	1	
28	514.0610.A	FASTENER INSULATION MAT CLIP	1	
29	514.0620.B	FASTENER TAPE UNDER SEAT DECK	1	
30	552.2010.A	SEAL SEAT DECK LH	1	
31	552.2020.A	SEAL SEAT DECK RH	1	
32	524.0001.K	BATTERY TRAY GENERAL Z36	1	
33	520.1000.B	FASTENERS BATTERY TRAY TO LF	1	




Click inside frame to activate 3D-view

Pos	Part no.	Description	Qty/Assy	Remarks
1	542.2020.B	CABLE TRACTION FEED TO PCU	1	Not illustrated
2	542.2025.A	FASTENER CBL TRACTION FEED TO PCU	1	
3	543.1160.B	SWITCH - INERTIA	1	
4	543.1220.A	FASTENER SWITCH INERTIA	1	
5	542.1090.G	MAINS DISTR. INLET ASSY - IEC-309	1	
6	542.1095.A	FASTENER MAINS DISTR. INLET ASSY	1	




Click inside frame to activate 3D-view

Pos	Part no.	Description	Qty/Assy	Remarks
1	590.1010.D	TRANSAXLE	1	
2	539.1010.I	ASSY-GEARSHIFT CONTROL	1	
3	539.1080.D	FASTENERS-GEARSHIFT CONTROL	1	
4	539.1020.E	CABLE,GEARSHIFT CONTROL	1	
5	539.1030.D	BRKT-GEARSHIFT CONTROL CABLE	1	
6	539.1040.D	FASTENERS-GEARSHIFT CABLE BRACKET	1	
7	533.1021.G	DRIVESHAFT, ABS, LH	1	
8	533.1022.G	DRIVESHAFT, ABS, RH	1	
9	533.1030.E	FASTENERS-DRIVESHAFT	2	
10	53S.0710.A	GAITOR DRIVESHAFT INNER	2	
11	53S.0810.A	GAITOR DRIVESHAFT OUTER	2	




Click inside frame to activate 3D-view

Pos	Part no.	Description	Qty/Assy	Remarks
1	530.1011.D	ASSY-STRUT, MANUAL & ABS, LH	1	
2	53S.0010.A	FRONT COIL SPRING	2	
3	53S.0020.A	BUMP SPACER t=20	2	
4	53S.0030.A	FRONT BUMP STOP l=66	2	
5	53S.0040.A	SHOCK ABSORBER	2	Not illustrated
6	53S.0050.A	REST CUP (SPRING PLATE UPR)	2	
7	53S.0060.A	THRUST BEARING	2	
8	53S.0070.A	CONTROL CUP (LOWER)	2	Not illustrated
9	53S.0080.A	SHOCK ABSORBER BRACKET UPPER	2	
10	53S.0090.A	CONTROL CUP (UPPER)	2	Not illustrated
11	53S.0100.A	SHOCK ABSORBER BELLOWS	2	
12	53S.0110.A	NUT M12X1.25-11.2. SHOCK ABSORBER	2	
13	53S.0120.A	CUP NUT SHOCK ABSORBER RETENTION	2	Not illustrated
14	53S.0131.A	SUSPENSION PIVOT ABS LH	1	
15	53S.0140.A	STEERING ARM MANUAL	2	
16	53S.0150.A	DAMPER HOUSING	2	Not illustrated
17	53S.0160.A	REST CUP (SPRING PLATE LWR)	2	
18	53S.0170.A	WHEEL HUB	2	
19	53S.0180.A	WHEEL BEARING	2	
20	53S.0190.A	STOP RING 72X76.5 t=2.5	2	
21	530.1040.B	FASTENERS-STRUT	2	
22	530.1031.B	ASSY-LOWER CONTROL ARM,LH	1	
23	53S.0260.A	BALL JOINT	2	
24	530.1080.B	FASTENERS-CONTROL ARM	2	
25	530.1140.B	PROTECTOR	1	
26	530.1012.D	ASSY-STRUT, MANUAL & ABS, RH	1	
27	53S.0132.A	SUSPENSION PIVOT ABS RH	1	
28	530.1032.B	ASSY-LOWER CONTROL ARM,RH	1	
29	530.3010.D	STABILIZER BAR, FRONT SUSPENSION Ø21	1	
30	530.3030.C	INNER BUSH,FRONT STAB BAR Ø21	2	
31	530.3040.B	INNER BRACKET,FRONT STAB BAR	2	
32	530.3020.D	FASTENERS-FRONT STAB BAR INNER	1	
33	530.3070.C	OUTER BUSH,FRONT STAB BAR Ø21	2	
34	530.3080.B	OUTER BRACKET,FRONT STAB BAR	2	
35	530.3060.C	FASTENERS-FRONT STAB BAR OUTER	1	




Click inside frame to activate 3D-view

Pos	Part no.	Description	Qty/Assy	Remarks
1	531.1010.G	ASSY-REAR SUSPENSION	1	
2	53S.0271.A	SUPPORT RH CROSSMEMBER AXLE RR	1	
3	53S.0272.A	SUPPORT LH CROSSMEMBER AXLE RR	1	
4	53S.0280.A	BODY CROSSMEMBER AXLE RR	1	
5	53S.0291.A	END PIECE LH CROSSMEMBER RR AXLE RR	1	
6	53S.0292.A	END PIECE RH CROSSMEMBER RR AXLE RR	1	
7	53S.0301.A	TORSION BAR RR LH Ø19	1	
8	53S.0302.A	TORSION BAR RR RH Ø19	1	
9	53S.0310.A	STABILIZER BAR RR Ø18	1	
10	53S.0320.A	FLEXIBLE MOUNTING FRT CROSSMEMBER RR	2	
11	53S.0330.A	FLEXIBLE MOUNTING RR CROSSMEMBER RR	2	
12	53S.0341.A	LEVER LH STABILIZER BAR RR ASSY	1	
13	53S.0342.A	LEVER RH STABILIZER BAR RR ASSY	1	
14	53S.0350.A	SEAL OUTER ARM SUSPENSION RR	2	
15	53S.0360.A	SEAL INNER ARM SUSPENSION RR	2	
16	53S.0371.A	DUST SEAL LH	1	
17	53S.0372.A	DUST SEAL RH	1	
18	53S.0380.A	SEAL TIGHTNESS LEVER BAR STABILIZER	2	
19	53S.0390.A	PLUG. ARM SUSPENSION Ø12 H12	1	
20	53S.0400.A	CAP SCREW M8X125 L14	4	
21	53S.0410.A	RETAINER. TORSION BAR RR	4	
22	53S.0420.A	BRAKE SCREW M8X125 L25	2	
23	53S.0431.A	ARM SUSPENSION LH	1	
24	53S.0432.A	ARM SUSPENSION RH	1	
25	53S.0440.A	SPINDLE RR	2	
26	53S.0450.A	HUB SEAL INNER Ø35	2	
27	53S.0460.A	SEALING CONNECTION. WHEEL BEARING	2	
28	53S.0470.A	PLAIN WASHER	2	
29	53S.0480.A	RETAINING RING	2	
30	53S.0490.A	PLUG	2	
31	53S.0500.A	HUB NUT M22X150-16.5-32	2	
32	53S.0510.A	SHOCK ABSORBER RR ASSY	2	
33	53S.0520.A	SCREW M12X175 L125 UPPER SHOCK ABSORB	2	
34	53S.0530.A	SCREW M14X150 L130 LOWER SHOCK ABSORB	2	
35	53S.0540.A	NUT M12X175 UPPER SHOCK ABSORBER	2	
36	53S.0550.A	NUT M14X150 LOWER SHOCK ABSORBER	2	



Click inside frame to activate 3D-view

Pos	Part no.	Description	Qty/Assy	Remarks
37	53S.0600.A	WHEEL BEARING RR	2	
38	531.2010.H	FASTENERS-REAR SUSPENSION	1	
39	531.2070.B	BUMP STOP, REAR	2	
40	531.2080.A	BUMP STOP BRKT, REAR	2	
41	560.8210.A	FASTENERS BUMP STOP	1	



Click inside frame to activate 3D-view